




P606MH




1x

Если встраиваемый духовой шкаф меньше ниши и после установки образуется щель между духовым шкафом и вязкой, ее необходимо закрыть входящей в состав модуля планкой 600*45.



09.09.2024

P606MH(1)




В мебельном наборе могут быть конструктивные изменения, не ухудшающие качество изделия, но не указанные в данной инструкции.

In furniture KIT, there may be changes, not specified in this manual, which don't deteriorate the quality of the produkt.


!Внимание! Максимальная нагрузка на ящик составляет 12 кг.

!Remember! Total weight of goods in the drawer shouldn't be over 12 kg.

26




27




25


1




2














3






No	code	a*b	x
1	P606MH.01	2220*554	1
2	P606MH.02	2220*554	1
3	P600.01	600*554	1
4	P600.02	568*554	3
5	P600.03	568*540	1
6	N600.05	600*100	1
7	N302.01	450*250	2
8	N602.01	511*250	1
9	P606M.03	395*595	1
10	P606MH.03	840*295	2
11	N601.02	540*455	1
12	P606MH.04	811 mm	1
13	P606M.06	568*554	1






24




FM0030/FM0033
FMT0016



Внимание! Крепление пенала к стене крепёжным уголком обязательно! Крепёжные средства для крепления к стене не прилагаются, для разных материалов стен требуются различные крепления. Используйте крепёжные средства, подходящие для материала стен в Вашем доме.

Attention! Use mounting angle to mount high cabinet to the wall. Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home.


23




Внимание! Крепление пенала к рядомстоящим модулям межсекционной стяжкой обязательно!

Attention! Use connection screw to mount high cabinet to the nearest base and wall cabinets.


1




2




3




4




21




22




19




20




5




6




7




8




17




18




15




9




16




10




11



12



13



14

